



**GENERAL NOTES:**

1. PULL BOXES SHALL BE #3 1/2 AS PER CAL TRANS STANDARD SPECIFICATION OR CHRISTY N-9 OR APPROVED EQUAL.
2. PULL BOXES SHALL BE GROUTED PRIOR TO INSTALLATION OF CONDUCTORS, SLOPED TOWARD THE DRAIN HOLE. PLACE A LAYER OF ROOFING PAPER BETWEEN THE CRUSHING ROCK AND THE GROUT.
3. PULL LIDS BEFORE POURING CONCRETE AROUND PULL BOXES.
4. WRAP PULL BOX WITH ROOFING PAPER BEFORE BACKFILLING.
5. FUSE AT POINT OF SERVICE SHALL BE 60A IF #6 CONDUCTOR AND 40A IF #8 CONDUCTOR AND SHALL HAVE A TRON TYPE FUSE HOLDER. (SINGLE POLE)
6. INSTALL A ONE-FOOT RING OF CONCRETE, FOUR INCHES DEEP, AROUND THE WRAPPED PULL BOXES INSTALLED IN DIRT AREAS. SLOPED TO DRAIN AWAY FROM THE PULL BOX.

STREETLIGHTS  
CONCRETE PULL BOXES

REVISIONS  
12-8-05  
5-7-10

CITY OF KERMAN

STD  
NO.  
E-4